

Installation steps

	Step 1: Download the PDF drilling plan.
	Step 2: Print the PDF on A3 paper
	Step 3: Find the optimal location & height
	Step 4: Tape the drilling plan to the wall at the optimal location
	Step 5: Drill the holes
	Step 6: Remove drilling plan, insert plug and place hook
	Step 7: Mount power supply with 2 plugs & screws. Route the power cables.
	Step 8: Install the clock on the hook
	Step 9: Plug in the power cable at the lower side of the clock.
	Step 10: Set the correct time using the WIFI.